


37575

Xerox® Altalink® C8230/C8235/C8245/C8255/C8270  
Color Multifunction Printer

## Printer Tour

Optional accessories can be part of your printer setup. For details, refer to the *User Guide*.

Single-Pass Duplex Automatic Document Feeder (DADF)



To restart the printer, on the control panel, press the secondary power switch (1).  
For full printer power off, press the secondary power switch (1). Behind the front cover, press the main power switch (2).  
To select sleep mode, press the secondary power switch (1). At the printer control panel touch screen, touch a selection.

