

Xerox® VersaLink® B625
Multifunction Printer

xerox™

Copying



For details, refer to the *User Guide*.

1

X: 127–356 mm (4.88–14 in.)
Y: 76–216 mm (2–8.5 in.)

52–120 g/m²
(14 lb. Text–32 lb. Bond)

≤100 (75 g/m², 20 lb. Bond)



X: 25–355.6 mm (.98–14 in.)
Y: 25–215.9 mm (.98–8.5 in.)

Load the original documents.

2



Touch **Copy**, then and select the number of copies.

3



Select feature settings from the list, then touch **Start**.

