37575

Xerox® VersaLink® C415
Color Multifunction Printer

Printer Tour

Optional accessories can be part of your printer setup. For details, refer to the *User Guide*.







www.xerox.com/office/support